## NOTES:

SYSTEM INSTALLS BOTTOM TO TOP, LEFT TO RIGHT.
ACTUAL DIMENSIONS FOR RAINSCREEN ACM PANELS TO BE

- DETERMINED IN FIELD. 3. FRAMING SHOWN IS AN <u>EXAMPLE</u> ONLY. ACTUAL SUPPORT
- TO BE VERIFIED IN FIELD.
- 4. ALL FASTENERS MUST PENETRATE 3/4" MIN. THROUGH SUBSTRATE AND FRAMING.

THIS DETAIL IS GENERAL IN NATURE AND WILL BE MODIFIED TO MEET JOB SPECIFIC CONDITIONS

